

MAINTENANCE

GLUE DOWN

The Green-Flor® modular resilient flooring with the Top Protection Plus system have a PUR protection and are thus highly resistant to dirt, stains and wear. Nevertheless Green-Flor® modular resilient flooring also needs to be cleaned regularly. How often and how is dependent on the place where the floor is, and the degree to which it is being used. Regular maintenance keeps the floor not only more beautiful and hygienic, it is also has a direct impact on the life time of your floor.

Preventive care and prevention of damage

Applying a good entrance mat or matting, largely prevents the ingress of dirt and moisture into the building and consequently onto your floor. It must be sized in such a way that walking on it is inevitable, and must have at least the length of a few steps.

Do not use a rubber, in combination with the floor. Migration can lead to a permanent dark brown discoloration.

Provide chair legs and other furniture from additional protection in order to protect your floor.

Browse to www.scratchnomore.com for the best protection of your floor. Do not slide heavy objects across the floor.

If necessary, replace the wheels under office chairs with wheels with double support rollers of type W (soft)

Daily maintenance

Use a vacuum cleaner or a dust mop to remove dust and dirt. Use a damp mop or cloth with a neutral detergent to remove 'stubborn' dirt better. It is recommended to use a separate 'rinse-bucket' for optimum results. Depending on the situation mechanical maintenance can bring an even better result if necessary.

Periodic maintenance

Depending on the intensity of use, the amount of dirt that is walked in and the way the daily maintenance is performed, and especially in big public projects, a scrub-suck machine with neutral detergent and equipped with a suitable red pad or a dry buffing high speed machine at 900 rpm with white pad, will yield a better result.

LOOSE LAY

After installation

After installation it is essential to sweep and/or vacuum clean the floor in order to take away all dust and dirt. Then clean the floor with a neutral detergent (e.g. Dr.Schutz PU Cleaner). Depending on the total surface, a cleaning machine (with "white"pad) or a damp mop or cloth can be used. It is recommended to use a separate 'rinse-bucket' for optimum results.

Regular and daily maintenance

Regular maintenance is performed in the same manner as described under 'After installation'.

Periodic maintenance

Depending on the intensity of use, the amount of dirt that is walked in and the way the daily maintenance is performed, and especially in big public projects, a scrub-suck machine with neutral detergent and equipped with a suitable red pad or a dry buffing high speed machine at 900 rpm with white pad, will yield a better result.

Attention !

Observe the dilution recommendations of the manufacturer of the cleaning products according to the intended use and the method used.

In the case of deep dirt, restoration products must be implemented (type Dr.Schutz R. Intensive Cleaner for example).

Please note, some products are not recommended due to the surface protection:

- Pure chlorine products,
- Products based on pine,
- Products containing soap,
- Products containing strong solvents (e.g. acetone)
- Polishers and varnish products.

Preventive care and prevention of damage

Applying a good entrance mat or matting, largely prevents the ingress of dirt and moisture into the building and consequently onto your floor. It must be sized in such a way that walking on it is inevitable, and must have at least the length of a few steps.

Do not use rubber, in combination with the floor. Migration can lead to a permanent dark brown discoloration.

Provide chair legs and other furniture from additional protection in order to protect your floor. (do not use rubber based or metal protection) Browse to www.scratchnomore.com

for the best protection of your floor. Do not slide heavy objects across the floor.
If necessary, replace the wheels under office chairs with wheels with double support
rollers of type W (soft)